

EXTERIOR WOOD OIL OPAQUE

Very high-protection opaque impregnation for exterior vertical woodwork. The concentrated colors and ultra-matte powdery appearance of EXTERIOR WOOD OIL OPAQUE make it a very trendy decorative finish that highlights the grain and natural beauty of the wood.

- » Hides imperfections
- » Ultra-matte finish, raw wood feel on-film-forming
- » Double UV protection
- » All wood species
- » Direct application in 2 coats, wet on wet
- » Does not run.

TECHNICAL DATA

Product type

water-based

Cleaning tools

water

Coverage

+/- 10 m²/liter (may vary depending on the type of wood).

Drying time

between 2 coats: 20-40 min

Complete drying time

24 h

Transport

between 5°C et 25°C

Waste

Dispose of waste and empty packaging in accordance with local regulations.



0,75L 2,5L



PRE-TREATMENT

The wood must be sound, clean, and dry, free of resin, grease stains, or old protective coatings or varnishes, paints, stains, or oils (other than EXTERIOR WOOD OIL OPAQUE, which requires regular maintenance). Depending on the condition of the surface, CIRANOVA EXTERIOR DEEP CLEANER will improve the adhesion and durability of EXTERIOR WOOD OIL OPAQUE. If necessary, strip.

IMPORTANT: Light sanding (80-grit sandpaper) after preparation on all surfaces, especially smooth wood or wood with a glossy, shiny surface, will open the pores and facilitate penetration. Do not use steel wool. Do not continue sanding until polishing, as this will produce the opposite effect to the one intended.

APPLICATION

Ready to use: do not dilute. Shake well before and during use. Apply the first coat in the direction of the wood grain using a spalter (a wide brush), paying particular attention to grooves, joints, and ends (end grain). Allow to penetrate for 20 to 40 minutes. Note: The desired shade will appear after the second coat has dried. As soon as the wood loses its damp appearance, apply the second coat without waiting for the product to dry. If necessary, smooth it with a dry spalter after a few minutes to achieve a beautiful finish, without highlights or drips. These are signs of the formation of a surface film (if necessary, quickly remove them by lightly sanding them). **IMPORTANT:** to achieve optimal impregnation of the wood with EXTERIOR WOOD OPAQUE, ensure that the wood is dry (at least 3 days of good, warm weather before application) and that there will be no risk of rain within 24 hours after the second coat (do not apply to wood with a humidity level above 12%).

MAINTENANCE

As soon as the wood's color naturally lightens due to weathering and ultraviolet radiation, sand, dust, and clean the surface with Ciranova EXTERIOR MAINTENANCE CLEANER. Rinse thoroughly and let dry. Pretreat the thin areas first and then apply a new coat of EXTERIOR WOOD OIL OPAQUE.

If necessary (late maintenance), sand (80-grit sandpaper) then use EXTERIOR DEEP CLEANER before applying EXTERIOR WOOD OIL OPAQUE.

IMPORTANT: The appearance of impregnated wood naturally changes due to weathering and ultraviolet radiation: the color lightens, and over time, water runoff becomes less noticeable, and the wood appears to be getting wet. This characteristic change will indicate the need for maintenance.